

Troubleshooting



This section is designed to aid in the quick, accurate diagnosis of automotive problems. While automotive repairs can be made by many people, accurate troubleshooting is a rare skill for the amateur and professional alike.

In its simplest state, troubleshooting is an exercise in logic. It is essential to realize that an automobile is really composed of a series of systems. Some of these systems are interrelated; others are not. Automobiles operate within a framework of logical rules and physical laws, and the key to troubleshooting is a good understanding of all the automotive systems.

This section breaks the car or truck down into its component systems, allowing the problem to be isolated. The charts and diagnostic road maps list the most common problems and the most probable causes of trouble. Obviously it would be impossible to list every possible problem that could happen along with every possible cause, but it will locate MOST problems and eliminate a lot of unnecessary guesswork. The systematic format will locate problems within a given system, but, because many automotive systems are interrelated, the solution to your particular problem may be found in a number of systems on the car or truck.

USING THE TROUBLESHOOTING CHARTS

This book contains all of the specific information that the average do-it-yourself mechanic needs to repair and maintain his or her car or truck. The troubleshooting charts are designed to be used in conjunction with the specific procedures and information in the text. For instance, troubleshooting a point-type ignition system is fairly standard for all models, but you may be directed to the text to find procedures for troubleshooting an individual type of electronic ignition. You will also have to refer to the specification charts throughout the book for specifications applicable to your car or truck.

TOOLS AND EQUIPMENT

The tools illustrated in Chapter 1 (plus two more diagnostic pieces) will be adequate to troubleshoot most problems. The two other tools needed are a voltmeter and an ohmmeter. These can be purchased separately or in combination, known as a VOM meter.

In the event that other tools are required, they will be noted in the procedures.

Troubleshooting Engine Problems

See Chapters 2, 3, 4 for more information and service procedures.

Index to Systems

System	To Test	Group
Battery	Engine need not be running	1
Starting system	Engine need not be running	2
Primary electrical system	Engine need not be running	3
Secondary electrical system	Engine need not be running	4
Fuel system	Engine need not be running	5
Engine compression	Engine need not be running	6
Engine vacuum	Engine must be running	7
Secondary electrical system	Engine must be running	8
Valve train	Engine must be running	9
Exhaust system	Engine must be running	10
Cooling system	Engine must be running	11
Engine lubrication	Engine must be running	12

Index to Problems

Problem: Symptom	Begin at Specific Diagnosis, Number
Engine Won't Start:	
Starter doesn't turn	1.1, 2.1
Starter turns, engine doesn't	2.1
Starter turns engine very slowly	1.1, 2.4
Starter turns engine normally	3.1, 4.1
Starter turns engine very quickly	6.1
Engine fires intermittently	4.1
Engine fires consistently	5.1, 6.1
Engine Runs Poorly:	
Hard starting	3.1, 4.1, 5.1, 8.1
Rough idle	4.1, 5.1, 8.1
Stalling	3.1, 4.1, 5.1, 8.1
Engine dies at high speeds	4.1, 5.1
Hesitation (on acceleration from standing stop)	5.1, 8.1
Poor pickup	4.1, 5.1, 8.1
Lack of power	3.1, 4.1, 5.1, 8.1
Backfire through the carburetor	4.1, 8.1, 9.1
Backfire through the exhaust	4.1, 8.1, 9.1
Blue exhaust gases	6.1, 7.1
Black exhaust gases	5.1
Running on (after the ignition is shut off)	3.1, 8.1
Susceptible to moisture	4.1
Engine misfires under load	4.1, 7.1, 8.4, 9.1
Engine misfires at speed	4.1, 8.4
Engine misfires at idle	3.1, 4.1, 5.1, 7.1, 8.4

Sample Section

Test and Procedure	Results and Indications	Proceed to
4.1—Check for spark: Hold each spark plug wire approximately ¼" from ground with gloves or a heavy, dry rag. Crank the engine and observe the spark.	→ If no spark is evident: _____	→ 4.2
	→ If spark is good in some cases: _____	→ 4.3
	→ If spark is good in all cases: _____	→ 4.6


Specific Diagnosis

This section is arranged so that following each test, instructions are given to proceed to another, until a problem is diagnosed.

Section 1—Battery

Test and Procedure	Results and Indications	Proceed to
--------------------	-------------------------	------------

1.1—Inspect the battery visually for case condition (corrosion, cracks) and water level.



If case is cracked, replace battery:
If the case is intact, remove corrosion with a solution of baking soda and water (CAUTION: do not get the solution into the battery), and fill with water:

1.4
1.2

Inspect the battery case

1.2—Check the battery cable connections: Insert a screwdriver between the battery post and the cable clamp. Turn the headlights on high beam, and observe them as the screwdriver is gently twisted to ensure good metal to metal contact.




If the lights brighten, remove and clean the clamp and post; coat the post with petroleum jelly, install and tighten the clamp:
If no improvement is noted:

1.4
1.3

1.3—Test the state of charge of the battery using an individual cell tester or hydrometer.

If indicated, charge the battery. NOTE: If no obvious reason exists for the low state of charge (i.e., battery age, prolonged storage), proceed to:

1.4



ADD THIS NUMBER TO THE HYDROMETER READING TO OBTAIN THE CORRECTED SPECIFIC GRAVITY

SUBTRACT THIS NUMBER FROM THE HYDROMETER READING TO OBTAIN THE CORRECTED SPECIFIC GRAVITY

Specific Gravity (@ 80° F.)

Minimum	Battery Charge
1.260	100% Charged
1.230	75% Charged
1.200	50% Charged
1.170	25% Charged
1.140	Very Little Power Left
1.110	Completely Discharged

The effects of temperature on battery specific gravity (left) and amount of battery charge in relation to specific gravity (right)

1.4—Visually inspect battery cables for cracking, bad connection to ground, or bad connection to starter.

If necessary, tighten connections or replace the cables:

2.1


Section 2—Starting System

See Chapter 3 for service procedures

Test and Procedure	Results and Indications	Proceed to
--------------------	-------------------------	------------



Note: Tests in Group 2 are performed with coil high tension lead disconnected to prevent accidental starting.

<p>2.1 Test the starter motor and solenoid: Connect a jumper from the battery post of the solenoid (or relay) to the starter post of the solenoid (or relay).</p>	<p>If starter turns the engine normally: 2.2</p> <p>If the starter buzzes, or turns the engine very slowly: 2.4</p> <p>If no response, replace the solenoid (or relay). 3.1</p> <p>If the starter turns, but the engine doesn't, ensure that the flywheel ring gear is intact. If the gear is undamaged, replace the starter drive. 3.1</p>	
<p>2.2—Determine whether ignition override switches are functioning properly (clutch start switch, neutral safety switch), by connecting a jumper across the switch(es), and turning the ignition switch to "start".</p>	<p>If starter operates, adjust or replace switch: 3.1</p> <p>If the starter doesn't operate: 2.3</p>	
<p>2.3—Check the ignition switch "start" position: Connect a 12V test lamp or voltmeter between the starter post of the solenoid (or relay) and ground. Turn the ignition switch to the "start" position, and jiggle the key.</p>	<p>If the lamp doesn't light or the meter needle doesn't move when the switch is turned, check the ignition switch for loose connections, cracked insulation, or broken wires. Repair or replace as necessary: 3.1</p> <p>If the lamp flickers or needle moves when the key is jiggled, replace the ignition switch. 3.3</p>	



<p>2.4—Remove and bench test the starter, according to specifications in the engine electrical section.</p>	<p>If the starter does not meet specifications, repair or replace as needed: 3.1</p> <p>If the starter is operating properly: 2.5</p>	
<p>2.5—Determine whether the engine can turn freely: Remove the spark plugs, and check for water in the cylinders. Check for water on the dipstick, or oil in the radiator. Attempt to turn the engine using an 18" flex drive and socket on the crankshaft pulley nut or bolt.</p>	<p>If the engine will turn freely only with the spark plugs out, and hydrostatic lock (water in the cylinders) is ruled out, check valve timing: 9.2</p> <p>If engine will not turn freely, and it is known that the clutch and transmission are free, the engine must be disassembled for further evaluation: Chapter 3</p>	

Section 3—Primary Electrical System

Test and Procedure	Results and Indications	Proceed to
<p>3.1—Check the ignition switch “on” position: Connect a jumper wire between the distributor side of the coil and ground, and a 12V test lamp between the switch side of the coil and ground. Remove the high tension lead from the coil. Turn the ignition switch on and jiggle the key.</p>	<p>If the lamp lights: 3.2</p> <p>If the lamp flickers when the key is jiggled, replace the ignition switch: 3.3</p> <p>If the lamp doesn't light, check for loose or open connections. If none are found, remove the ignition switch and check for continuity. If the switch is faulty, replace it: 3.3</p>	
 <p>Checking the ignition switch “on” position</p>		
<p>3.2—Check the ballast resistor or resistance wire for an open circuit, using an ohmmeter. See Chapter 3 for specific tests.</p>	<p>Replace the resistor or resistance wire if the resistance is zero. NOTE: Some ignition systems have no ballast resistor.</p>	3.3
 <p>Two types of resistors</p>		
<p>3.3—On point-type ignition systems, visually inspect the breaker points for burning, pitting or excessive wear. Gray coloring of the point contact surfaces is normal. Rotate the crankshaft until the contact heel rests on a high point of the distributor cam and adjust the point gap to specifications. On electronic ignition models, remove the distributor cap and visually inspect the armature. Ensure that the armature pin is in place, and that the armature is on tight and rotates when the engine is cranked. Make sure there are no cracks, chips or rounded edges on the armature.</p>	<p>If the breaker points are intact, clean the contact surfaces with fine emery cloth, and adjust the point gap to specifications. If the points are worn, replace them. On electronic systems, replace any parts which appear defective. If condition persists:</p>	3.4

Test and Procedure	Results and Indications	Proceed to
<p>3.4—On point-type ignition systems, connect a dwell-meter between the distributor primary lead and ground. Crank the engine and observe the point dwell angle. On electronic ignition systems, conduct a stator (magnetic pickup assembly) test. See Chapter 3.</p>	<p>On point-type systems, adjust the dwell angle if necessary. NOTE: Increasing the point gap decreases the dwell angle and vice-versa.</p> <p>If the dwell meter shows little or no reading:</p> <p>On electronic ignition systems, if the stator is bad, replace the stator. If the stator is good, proceed to the other tests in Chapter 3.</p>	<p>3.6</p> <p>3.5</p>



Dwell is a function of point gap

<p>3.5—On the point-type ignition systems, check the condenser for short; connect an ohmmeter across the condenser body and the pigtail lead.</p>	<p>If any reading other than infinite is noted, replace the condenser</p>	<p>3.6</p>
---	---	------------



Checking the condenser for short

<p>3.6—Test the coil primary resistance: On point-type ignition systems, connect an ohmmeter across the coil primary terminals, and read the resistance on the low scale. Note whether an external ballast resistor or resistance wire is used. On electronic ignition systems, test the coil primary resistance as in Chapter 3.</p>	<p>Point-type ignition coils utilizing ballast resistors or resistance wires should have approximately 1.0 ohms resistance. Coils with internal resistors should have approximately 4.0 ohms resistance. If values far from the above are noted, replace the coil.</p>	<p>4.1</p>
---	--	------------



Check the coil primary resistance

Section 4—Secondary Electrical System

See Chapters 2–3 for service procedures


Test and Procedure	Results and Indications	Proceed to
<p>4.1—Check for spark: Hold each spark plug wire approximately ¼" from ground with gloves or a heavy, dry rag. Crank the engine, and observe the spark.</p>	<p>If no spark is evident: 4.2 If spark is good in some cylinders: 4.3 If spark is good in all cylinders: 4.6</p>	



Check for spark at the plugs

<p>4.2—Check for spark at the coil high tension lead: Remove the coil high tension lead from the distributor and position it approximately ¼" from ground. Crank the engine and observe spark. CAUTION: This test should not be performed on engines equipped with electronic ignition.</p>	<p>If the spark is good and consistent: 4.3 If the spark is good but intermittent, test the primary electrical system starting at 3.3: 3.3 If the spark is weak or non-existent, replace the coil high tension lead, clean and tighten all connections and retest. If no improvement is noted: 4.4</p>	
--	--	--

<p>4.3—Visually inspect the distributor cap and rotor for burned or corroded contacts, cracks, carbon tracks, or moisture. Also check the fit of the rotor on the distributor shaft (where applicable).</p>	<p>If moisture is present, dry thoroughly, and retest per 4.1: 4.1 If burned or excessively corroded contacts, cracks, or carbon tracks are noted, replace the defective part(s) and retest per 4.1: 4.1 If the rotor and cap appear intact, or are only slightly corroded, clean the contacts thoroughly (including the cap towers and spark plug wire ends) and retest per 4.1: 4.6 If the spark is good in all cases: 4.5 If the spark is poor in all cases: 4.5</p>	
---	---	--




Inspect the distributor cap and rotor

Test and Procedure	Results and Indications	Proceed to
--------------------	-------------------------	------------

4.4—Check the coil secondary resistance: On point-type systems connect an ohmmeter across the distributor side of the coil and the coil tower. Read the resistance on the high scale of the ohmmeter. On electronic ignition systems, see Chapter 3 for specific tests.

The resistance of a satisfactory coil should be between 4,000 and 10,000 ohms. If resistance is considerably higher (i.e., 40,000 ohms) replace the coil and retest per 4.1. **NOTE: This does not apply to high performance coils.**



Testing the coil secondary resistance


4.5—Visually inspect the spark plug wires for cracking or brittleness. Ensure that no two wires are positioned so as to cause induction firing (adjacent and parallel). Remove each wire, one by one, and check resistance with an ohmmeter.

Replace any cracked or brittle wires. If any of the wires are defective, replace the entire set. Replace any wires with excessive resistance (over 8000Ω per foot for suppression wire), and separate any wires that might cause induction firing.

4.6



Misfiring can be the result of spark plug leads to adjacent, consecutively firing cylinders running parallel and too close together



On point-type ignition systems, check the spark plug wires as shown. On electronic ignitions, do not remove the wire from the distributor cap terminal; instead, test through the cap



Spark plug wires can be checked visually by bending them in a loop over your finger. This will reveal any cracks, burned or broken insulation. Any wire with cracked insulation should be replaced

4.6—Remove the spark plugs, noting the cylinders from which they were removed, and evaluate according to the color photos in the middle of this book.

See following.

See following.

Test and Procedure	Results and Indications	Proceed to
--------------------	-------------------------	------------


4.7—Examine the location of all the plugs.

The following diagrams illustrate some of the conditions that the location of plugs will reveal.


4.8




Two adjacent plugs are fouled in a 6-cylinder engine, 4-cylinder engine or either bank of a V-8. This is probably due to a blown head gasket between the two cylinders




The two center plugs in a 6-cylinder engine are fouled. Raw fuel may be "boiled" out of the carburetor into the intake manifold after the engine is shut-off. Stop-start driving can also foul the center plugs, due to overly rich mixture. Proper float level, a new float needle and seat or use of an insulating spacer may help this problem




An unbalanced carburetor is indicated. Following the fuel flow on this particular design shows that the cylinders fed by the right-hand barrel are fouled from overly rich mixture, while the cylinders fed by the left-hand barrel are normal



If the four rear plugs are overheated, a cooling system problem is suggested. A thorough cleaning of the cooling system may restore coolant circulation and cure the problem



Finding one plug overheated may indicate an intake manifold leak near the affected cylinder. If the overheated plug is the second of two adjacent, consecutively firing plugs, it could be the result of ignition cross-firing. Separating the leads to these two plugs will eliminate cross-fire



Occasionally, the two rear plugs in large, lightly used V-8's will become oil fouled. High oil consumption and smoky exhaust may also be noticed. It is probably due to plugged oil drain holes in the rear of the cylinder head, causing oil to be sucked in around the valve stems. This usually occurs in the rear cylinders first, because the engine slants that way

